

# REPCO Pump Puller

A simple method for the installation and removal of residential well pumps. Locate the Pump Puller directly over the well, attach the lifting cable to the pitless adapter and push the power up button. The pipe and wire wind up on the drum like fishing line on a reel. The well pipe and wire are out of harms way, off of the grass and dirt, clean and sterile. You should have one of these machines!



A Pump Puller that may also be used as a Pump Installer.

Specifications:

1/2 HP, 115 Volt, 60 Hz

600 Ft, 1" 160 PSI Capacity

500 Lb. Lifting Capacity

Power-Up

Free Wheel Down

Easily Operated by One Man

**R. E. PRESCOTT CO., INC.**

**1-800-479-4320**

**EXETER, NH 03833**